

COGN410

Prepare Beta/Gamma radiation/contamination controlled work areas



Overview

This unit covers the competence required to prepare beta/gamma radiation or contamination controlled work areas and may be applied to Post Operational Clean Out (POCO). Generally, this unit should be applied to the work undertaken to prepare the work area for an activity which aids nuclear decommissioning and will not include positioning and construction of equipment.

This unit deals with the following:

1. Prepare beta/gamma radiation/contamination controlled work areas

During this work you must take account of the relevant worksite operational requirements, procedures and safe working practices AS THEY APPLY TO YOU.

Previous Version:

Adapted from Unit N410 of Nuclear Decommissioning NOS – version October 2005.

COGN410

Prepare Beta/Gamma radiation/contamination controlled work areas

Performance criteria

- You must be able to:*
- P1 work safely at all times, complying with health and safety and other relevant regulations and guidelines
 - P2 ensure that the work environment is free from hazards and obstructions and is suitable for the work activities to be undertaken
 - P3 ensure that all necessary service supplies are connected and ready for use
 - P4 **prepare** the work areas so that they are ready for the engineering activities to be carried out
 - P5 make sure that required safety arrangements are in place to protect other workers from any activities which are likely to disrupt normal working
 - P6 inform the appropriate people when work area preparations are completed
 - P7 deal promptly and effectively with problems within your control and report those that cannot be solved

COGN410

Prepare Beta/Gamma radiation/contamination controlled work areas

Knowledge and understanding

You need to know and understand:

- K1 health and safety legislation, regulations and safe working practices and procedures
- K2 the requirements and methods for work area preparation
- K3 the consequences of not preparing work areas correctly
- K4 service supply and connection procedures
- K5 how to identify materials and recognise defects
- K6 material handling and preparation methods and techniques
- K7 the properties and hazards associated with working in beta/gamma radiation areas
- K8 the use of 'working time limits' in the control of beta/gamma radiation exposure
- K9 tool and equipment care and control procedures
- K10 reporting lines and procedures

COGN410

Prepare Beta/Gamma radiation/contamination controlled work areas

Additional Information

Glossary

The following terms have a specific meaning in this unit:

Prepare

- Floor coverings
- Support services
- Disposal containers
- Barriers and notices

COGN410

Prepare Beta/Gamma radiation/contamination controlled work areas

Developed by Cogent

Version number 1

Date approved September 2008

Indicative review date September 2010

Validity Current

Status Original

Originating organisation Cogent

Original URN N410

Relevant occupations Professional Occupations; Engineering Professionals; Engineering and manufacturing technology; Engineering

Suite Nuclear Decommissioning

Key words beta, gamma, radiation, contamination, prepare